









**Step 6: Finger tighten the two clevis's onto the bolts.
Once finger tight, turn with 5/8" wrench
until they are vertical (up and down).
DO NOT TIGHTEN more than half a turn!**



